

PCS 7 CPU 410-5H	Order no.	Operating system firmware version	PCS 7 version	Link to the download page
CPU 410-5H	6ES7 410-5HX08-0AB0	V8.0.2	PCS 7 V8.0 SP1 + HUP CPU 410-5H	Entry ID: 109476571
		V8.1.2	*	

*The CPU 410-5H firmware V8.1.x can be used independently of SIMATIC PCS 7 V8.1. In this way you can also benefit from the corrections for the CPU410-5H listed below if you are using SIMATIC PCS 7 V8.0.

CPU 412	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
CPU 412-1	6ES7 412-1XF00-0AB0	A3	---	Entry ID: 109475012
	6ES7 412-1XF01-0AB0	A9	---	
	6ES7 412-1XF02-0AB0	A9	---	
	6ES7 412-1XF03-0AB0	V3.1.4	---	
	6ES7 412-1XF04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 412-1XJ05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
CPU 412-2	6ES7 412-2XG00-0AB0	V3.1.4	---	Entry ID: 109475012
	6ES7 412-2XG04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 412-2XJ05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
	6ES7 412-2EK06-0AB0	V6.0.2	STEP 7 V5.5	Entry ID: 109474874
	6ES7 412-2EK07-0AB0	V7.0.0	STEP 7 V5.5	Entry ID: coming soon
CPU 412-3H	6ES7 412-3HJ14-0AB0	V4.5.7	STEP 7 V5.3 SP2/ F-Systems	Entry ID: 109474703
CPU 412-5H	6ES7 412-5HK06-0AB0	V6.0.5	STEP 7 V5.5 SP2 HF1/ F-Systems	Entry ID: 109474550

CPU 413	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
CPU 413-1	6ES7 413-1XG00-0AB0	A3	---	Entry ID: 109475012
	6ES7 413-1XG01-0AB0	A9	---	
	6ES7 413-1XG02-0AB0	A9	---	
CPU 413-2	6ES7 413-2XG00-0AB0	A4	---	Entry ID: 109475012
	6ES7 413-2XG01-0AB0	A9	---	
	6ES7 413-2XG02-0AB0	A9	---	

CPU 414	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
CPU 414-1	6ES7 414-1XG00-0AB0	A3	---	Entry ID: 109475012
	6ES7 414-1XG01-0AB0	A9	---	
	6ES7 414-1XG02-0AB0	A9	---	
CPU 414-2	6ES7 414-2XG00-0AB0	A4	---	Entry ID: 109475012
	6ES7 414-2XG01-0AB0	A9	---	
	6ES7 414-2XG02-0AB0	A9	---	
	6ES7 414-2XG03-0AB0	V3.1.4	---	
	6ES7 414-2XG04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 414-2XJ00-0AB0	A9	---	Entry ID: 109475012
	6ES7 414-2XJ01-0AB0	A9	---	
	6ES7 414-2XK05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
CPU 414-3	6ES7 414-3EM05-0AB0	V5.3.2	STEP 7 V5.4 SP4	Entry ID: 109474827
	6ES7 414-3XJ00-0AB0	V3.1.4	---	Entry ID: 109475012
	6ES7 414-3XJ04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 414-3XM05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
	6ES7 414-3EM06-0AB0	V6.0.4	STEP 7 V5.5	Entry ID: 109474874

CPU 414	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
	6ES7 414-3EM07-0AB0	V7.0.0	STEP 7 V5.5	Entry ID: coming soon
CPU 414F-3	6ES7 414-3FM06-0AB0	V6.0.4	STEP 7 V5.5/ Distributed Safety V5.4	Entry ID: 109474874
	6ES7 414-3FM07-0AB0	V7.0.0	STEP 7 V5.5	Entry ID: coming soon
CPU 414-4H	6ES7 414-4HJ00-0AB0	V3.1.5	STEP 7 V5.0 SP2/ F-Systems	Entry ID: 6741018
	6ES7 414-4HJ04-0AB0	V4.0.12	STEP 7 V5.0 SP2/ F-Systems	Entry ID: 109474747
	6ES7 414-4HM14-0AB0	V4.5.7	STEP 7 V5.3 SP2/ F-Systems	Entry ID: 109474703
	6ES7 414-4HR14-0AB0	V4.5.7	STEP 7 V5.3 SP2/ F-Systems	Entry ID: 109474703
CPU 414-5H	6ES7 414-5HM06-0AB0	V6.0.5	STEP 7 V5.5 SP2 HF 1/ F-Systems	Entry ID: 109474550

CPU 416	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
CPU 416-1	6ES7 416-1XJ00-0AB0	A3	---	Entry ID: 109475012
	6ES7 416-1XJ01-0AB0	A9	---	
	6ES7 416-1XJ02-0AB0	A9	---	
CPU 416-2	6ES7 416-2XK00-0AB0	A9	---	Entry ID: 109475012
	6ES7 416-2XK01-0AB0	A9	---	
	6ES7 416-2XK02-0AB0	V3.1.4	---	
	6ES7 416-2XK04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 416-2XL00-0AB0	A9	---	Entry ID: 109475012

CPU 416	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
	6ES7 416-2XL01-0AB0	A9	---	
	6ES7 416-2XN05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
CPU 416F-2	6ES7 416-2FK02-0AB0	V3.1.4	---	Entry ID: 109475012
	6ES7 416-2FK04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 416-2FN05-0AB0	V5.3.5	STEP 7 V5.3 SP2/ Distributed Safety V5.4	Entry ID: 109474827
CPU 416-3	6ES7 416-3ER05-0AB0	V5.3.2	STEP 7 V5.4 SP4	Entry ID: 109474827
	6ES7 416-3XL00-0AB0	V3.1.4	---	Entry ID: 109475012
	6ES7 416-3XL04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 416-3XR05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
	6ES7 416-3ES06-0AB0	V6.0.4	STEP 7 V5.5	Entry ID: 109474874
	6ES7 416-3ES07-0AB0	V7.0.0	STEP 7 V5.5	Entry ID: coming soon
CPU 416F-3	6ES7 416-3FR05-0AB0	V5.3.2	STEP 7 V5.4 SP4/ Distributed Safety V5.4	Entry ID: 109474827
	6ES7 416-3FS06-0AB0	V6.0.4	STEP 7 V5.5/ Distributed Safety V5.4 SP1	Entry ID: 109474874
	6ES7 416-3FS07-0AB0	V7.0.0	STEP 7 V5.5	Entry ID: coming soon
CPU 416-5H	6ES7 416-5HS06-0AB0	V6.0.5	STEP 7 V5.5 SP2 HF1	Entry ID: 109474550

CPU 417	Order no.	Operating system firmware version	STEP 7 version	Link to the download page
CPU 417-4	6ES7 417-4XL00-0AB0	V3.1.4	---	Entry ID: 109475012
	6ES7 417-4XL04-0AB0	V4.1.1	STEP 7 V5.2 SP1 HF3	Entry ID: 109474988
	6ES7 417-4XT05-0AB0	V5.3.5	STEP 7 V5.3 SP2	Entry ID: 109474827
	6ES7 417-4XT07-0AB0	V7.0.0	STEP 7 V5.5	Entry ID: coming soon
CPU 417-4H	6ES7 417-4HL00-0AB0	V2.1.5	---	Entry ID: 6741018
	6ES7 417-4HL01-0AB0	V3.1.5	---	
	6ES7 417-4HL04-0AB0	V4.0.12	STEP 7 V5.2 SP1 HF3/ F-Systems	Entry ID: 109474747
	6ES7 417-4HT14-0AB0	V4.5.7	STEP 7 V5.3 SP2/ F-Systems	Entry ID: 109474703
CPU 417-5H	6ES7 417-5HT06-0AB0	V6.0.5	STEP 7 V5.5 SP2 HF1/ F-Systems	Entry ID: 109474550

Last update: 12/2015